

# Glue Down Your Floor Transition



Our floor transition has been just laying on top of the floor for about a year now, and is easily kicked out of place on accident all the time! The wood flooring transition comes with a little track that the transition snaps into. The tile flooring in my kitchen is taller than the living room wood floors, so the space in between is too deep for the track to reach! Our solution? RapidFuse to the rescue!

Items Needed:  
RapidFuse

## INSTRUCTIONS

1. Apply DAP RapidFuse to the sides of the transition so it can bond with the wood floors and the tile.
2. Find something heavy to weigh it down with while the glue cures. We used some left over floor tiles piled on top of the transition across the whole doorway. We left the tiles on top of the transition for a few hours, just to ensure the bond was tight!



Constantly getting kicked out of place!



RapidFuse applied.



Getting ready to put it in its place!



Creative weights.

Dry and looking good!

